



# COLLE VINYL ET INTISSÉS

## PASTE FOR VINYL AND NON-WOVENS

### TECHNICAL DEFINITION.

Paste for all types of vinyl wallpaper: flat vinyl, expanded vinyl wallpaper, heavy wallpaper and for non-wovens and non-woven backed paper.

### SUITABLE SUBSTRATES.

- Plaster boards.
- Plaster blocks.
- Concrete or cement coating.
- Plaster.

### YIELD.

- 300 g for 6 rolls.
- Vinyls: approximately 30 m<sup>2</sup>.
- Non-wovens: approximately 35 m<sup>2</sup>.

### PACKAGING.

300 g box.

### STORAGE.

Store in a dry place.

## APPLICATION

### PREPARATION OF SUBSTRATES

Substrates must be sound, dust-free, dry and normally absorbent.

Remove old coverings with a wallpaper removal product such as Sem-Decolleur.

Treat absorbent surfaces with a primer.

Sand, wash down and rinse old paintwork.

### PREPARATION OF THE PASTE.

Pour the right amount of cold water (for the 300 g carton) into a clean container.

Vinyls: 5 l.

Non-wovens: 4.5 l.

Stir the water and pour in the contents of the box, mixing all the time.

Let it stand 3 for minutes and mix again vigorously. The paste is ready.

### APPLICATION.

#### PASTING OF NON-WOVENS.

Apply the paste to the wall directly using a medium-pile roller.

Place the covering on the wall and smooth out working from the centre towards the edge.

#### PASTING OF VINYL.

Paste the reverse side of the covering with a brush, fold the 2 ends edge to edge and let the covering soak according to the manufacturer's instructions.

Apply the paper to the top of the wall and smooth it from the top down and from the centre toward the edges.

The surplus paste which emerges along the joins must be removed immediately with a damp sponge.

Cut off the surplus covering with a knife at the top and bottom.

Laying coverings must be carried out in accordance with standard DTU 59-4.

Adhesive suitable for use in a pasting machine.

## POWDER WALL- PAPER PASTE LIGHT AND HEAVY PAPERS

Ideal paste for all standard and non-woven wallpapers.

### ADVANTAGES

- Ready in 3 minutes.
- Easy preparation without lumps.
- High tacking power.

### APPLICATION TIP

In order to ensure the quality of the mixture, respect the instructions for preparing the paste which is in three steps:

- 1- Dispersion of the powder in the water for two minutes.
- 2- Letting it settle so that the active principles can expand (3 mins)
- 3- Vigorous stirring to obtain perfectly smooth and creamy paste.

